

HOW TO PROPERLY LOAD YOUR APEXARMOR QUICKSEAL GUN

QUICK STEP-BY-STEP SETUP GUIDE

1 OPEN FRONT LOCKING CLIP

Pull the front locking clip down.



2 INSERT PLUNGER

Slide the plunger into the gun with the teeth side down.



PRO TIP: Load the plunger teeth side down.



3 REMOVE CAP PLUG

Remove the cap plug from the cartridge.



4 ATTACH MIXING TIP

Install the mixing tip onto the cartridge.

The mixing tip can be attached before or after cartridge installation.



5 LOAD CARTRIDGE & LOCK

Slide the cartridge into the locking clip and push everything back into place.



6 READY TO USE

Your ApexArmor QuickSeal gun is loaded and ready for repairs.



QUICK, PROFESSIONAL-GRADE REPAIRS.

Apply ApexArmor QuickSeal with confidence for fast, durable repairs on cracks, gaps, and roof penetrations.



**SCAN TO WATCH
STEP-BY-STEP VIDEO**

Video install instructions



NEED ASSISTANCE?

Contact us at: sales@sprayriteusa.com